



DC RESISTANCE TESTER
USERS MANUAL
3544

Mar, 2021
Rev2.4

INTRODUCTION	6
CHECKING PACKAGE CONTENTS.....	6
SECURITY INFORMATION	8
USAGE NOTES	10
CHAPTER I OVERVIEW.....	13
1.1 INTRODUCTION	13
1.2 FEATURES.....	14
1.3 COMPONENT NAME AND FUNCTIONALITY	15
1.4 DIMENSIONS	19
1.5 PAGE COMPOSITION	19
CHAPTER II PREPARING FOR MEASUREMENT	22
2.1 MEASUREMENT PROCESS OVERVIEW	22
2.2 BASIC PARAMETER SETTING PROCESS	24
2.3 PRE-MEASUREMENT INSPECTION	25
2.4 CONFIRMING THE MEASURED OBJECT	26
2.5 CONNECTING MEASUREMENT LEADS.....	27
CHAPTER III BASIC SETTINGS.....	29
3.1 SETTING THE TEST RANGE	29
3.2 SETTING THE MEASUREMENT SPEED	30
3.3 TEMPERATURE DISPLAY SETTINGS.....	31
3.4 SETTING THE TEST TRIGGER MODE.....	32
3.5 MEASUREMENT DELAY SETTING	33
3.6 OVC (THERMAL ELECTROMOTIVE FORCE COMPENSATION) FUNCTION SETTING	35
3.7 SWITCHING MEASUREMENT CURRENT 300MA (300MΩ RANGE)	37
3.8 TEMPERATURE COMPENSATION SETTING	39
3.9 AVERAGE FUNCTION.....	41
3.10 SETTING BEEP.....	42

3.11	BUTTON SOUND SETTING	44
3.12	LANGUAGE SETTING	44
3.13	COMPARATOR FUNCTION	45
3.13.1	<i>Comparing result signal output method</i>	45
3.13.2	<i>Comparison Mode</i>	46
3.13.3	<i>Setting upper and lower limits & compare mode</i>	48
3.14	SORTING FUNCTION	48
3.14.1	<i>Sorting Function Opening Setting</i>	49
3.14.2	<i>Sorting Function Range Setting</i>	49
3.14.3	<i>Sorting Function Group No. Setting</i>	50
3.14.4	<i>Sorting Function Upper Limit Setting</i>	50
3.14.5	<i>Sorting Function Lower Limit Setting</i>	51
3.14.6	<i>Return to Display Page</i>	51
CHAPTER IV MEASURING		52
4.1	STARTING.....	52
4.2	MEASURING VALUE DISPLAY	53
4.3	AUTOMATIC PROTECTION FUNCTION.....	54
4.4	PERFORM CLEAR ZERO	54
CHAPTER V MEASURE PANEL SAVE		58
5.1	SAVE PANEL SETTING.....	58
5.2	RETRIEVE MEASURING SETTING	59
5.3	DELETE MEASURING SETTING	60
5.4	RENAME MEASURING SETTING	60
CHAPTER VI EXT I/O PORT (HANDLER)		61
6.1	EXT I/O PORT AND SIGNAL	62
6.1.1	<i>Level Mode Settings</i>	62
6.1.2	<i>Port Signals description</i>	64
6.1.3	<i>Port Signal Connection Method</i>	67
6.2	TIMING CHART.....	69
6.2.1	<i>Timing chart for external triggering</i>	69

6.2.2 Reading process at external triggering	71
6.3 EXTERNAL CONTROL CHECKING	72
CHAPTER VII COMMUNICATIONS.....	74
7.1 RS232 COMMUNICATION	74
7.2 RS485 COMMUNICATION	76
7.3 LAN COMMUNICATION	78
CHAPTER VIII SPECIFICATION	80
8.1 GENERAL SPECIFICATION	80
8.2 ACCURACY	82

Introduction

Thank you for purchasing 3544 DC resistance Tester. To obtain maximum performance from the product, please read this manual first, and keep it handy for future reference.

Registered trademarks

Windows and Excel are registered trademarks of Microsoft Corporation in the United States or other countries.


Checking Package Contents

When you receive the instrument, inspect it carefully to ensure that no damage occurred during shipping. In particular, check the accessories, panel switches, and connectors. If damage is evident, or if it fails to operate according to the specifications, contact your authorized distributor or reseller.


To transport this instrument, use the original packaging and wrap it in a double carton. Damage in transit is not warranty.

Check the package contents as follows:


No.	Item	Quantity
1	DC Resistance Tester	1
2	RS232 communication cables	1
3	Test Lead	1
4	Power cord	1
5	User manual	1



3544 DC resistance tester



Test Lead







RS232 communication cables

Security information





The instrument is designed to conform to IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, if it is used improperly, it may cause injury or death and damage the instrument. Be sure to read through this manual and its precautions before use. Our company does not assume any responsibility for accidents and injuries not caused by defects in the instrument itself.

Safety signs

This manual contains information and warnings essential for safe operation of the instrument and for maintaining it in safe operating condition. Before using the instrument, be certain to read the following safety notes carefully.

	Indicates very important message in this manual. When the symbol is printed on the instrument, refer to a corresponding topic in the Instruction Manual.
	Indicates DC (direct current)
	Indicates a fuse
	Indicates earth terminal

In this manual, the risk seriousness and the hazard levels are classified as follows:

 DANGER	Indicates an imminently hazardous situation that will result in death or serious injury to the operator.
 WARNING	Indicates a potentially hazardous situation that will result in death or serious injury to the operator.
 CAUTION	Indicates a potentially hazardous situation that may result in minor or moderate injury to the operator or damage to the instrument or malfunction.
 NOTE	Indicates functions of the instrument or relative suggestion of a correct operation.

Accuracy

We define measurement tolerances in terms of f.s. (full scale), rdg. (reading) and dgt. (digit) values, with the following meanings:

f.s. (Maximum display value)

This is usually the maximum display value. In the instrument, this indicates the currently used range.

rdg. (Reading or displayed value)

The value currently being measured and indicated on the measuring instrument.

dgt. (Resolution)

The smallest displayable unit on a digital measuring instrument, i.e., the input value that causes the digital display to show a “1”.

Usage Notes

Installation environment

Operating temperature and humidity range:

0°C to 40°C, 80%RH or less (no condensation)

Ideal working temperature and humidity range:


23 ± 5°C, 80%RH or less (no condensation)

To avoid failure or damage to the instrument, do not place the tester in the following places:



- Places exposed to direct sunlight or high temperatures
- Places exposed to high humidity or condensation
- Places exposed to large amounts of dust particles
- Places exposed to water, oil, chemicals or solvents
- Places exposed to corrosive or combustible gases
- Places with strong electromagnetic fields or electromagnetic radiation
- Places where mechanical vibration is frequent

Checking before use



Before using the instrument the first time, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, please contact us.

	<p>Before using the instrument, check that the coating of the test leads or cables are not torn and that no metal parts are exposed. Using the instrument under such conditions could result in electrocution. Contact your authorized distributor or reseller in this case.</p>
---	--

Use of instruments



 DANGER	To avoid electric shock, do not disassemble the instrument electronic enclosure. There are high pressure and high temperature parts inside the instrument during operation.
 CAUTION	Do not place the instrument on an unstable or slanted surface. It may drop or fall, causing injury or instrument failure.

Measurement considerations

 DANGER	<p>To avoid electric shocks and short circuits, the following procedures must be followed:</p> <p>Please do not wet this instrument or measure with wet hands. Otherwise, it will lead to electric shock accident.</p> <p>Do not modify, disassemble or repair. Otherwise, it will cause fire, electric shock accident or personnel injury.</p>
 CAUTION	<p>In order to prevent damage to this instrument, please avoid vibration and collision during handling and use. Pay special attention to the collision caused by falling.</p> <p>Do not connect measuring terminals to EX.I/O terminals and</p>

	communication terminals to avoid damage to this instrument.
--	---

Use of test leads and cables

 DANGER	<p>To avoid electrical shock accident, do not short test leads where voltage is applied.</p>
 CAUTION	<p>Do not use any test lead or temperature sensor other than the ones specified by our company. It may result in inaccurate measurement due to poor contact or other reasons.</p> <p>To avoid damaging the cables, do not bend or pull the base of cables and the leads.</p> <p>To avoid damage to the test leads, when plug/pull the test line, don't hold the cable but connector.</p>

Chapter I Overview

1.1 Introduction

The 3544 is a resistance tester with high precision and wide range and high performance microprocessor.

The 3544 has a measuring range from $3\text{m}\Omega$ to $3\text{M}\Omega$ to test resistors from $0.1\mu\Omega$ to $3\text{M}\Omega$ with a maximum display of 32000. At a test speed of 15 times/second, 0.02% accuracy is still guaranteed, and the reading jitter can be controlled within 3 words. Its unique OVC test mode can be adapted to high-precision test requirements. Since the instrument incorporates a temperature correction function, it is particularly well suited to the measurement of targets whose resistance values vary with temperature.

The 3544 series instruments support scan test function. With the company's multi-channel scanning tester, it is possible to simultaneously scan and measure multiple resistors.

The instrument has sorting function, with 10 sets of panel storage and various sorting beeper setting, and can also be equipped with Handler interface, which is applied to the automatic sorting system to complete the automatic pipeline test. It is equipped with RS232, RS485 and Ethernet interfaces for remote control and data acquisition and analysis.

The computer remote control command is compatible with SCPI (Standard Command for Programmable Instrument), which can efficiently perform remote control and data acquisition functions.

The instrument can measure a variety of high, medium and low value resistors; various switch contact resistors; connector contact resistors; relay wire packs and contact resistors; transformer, inductor, motor, deflection coil winding resistance; wire resistance; metal riveting resistance of cars, ships, aircraft; printed lines and pore resistance, etc.

1.2 Features

Appearance

- Display with 3.5-inch high-resolution TFT screen display, easy to operate
- Compact design

Reliable specifications even if the body is small and light weight

- High resolution of 32,000 dgt.
- 0.1 $\mu\Omega$ resolution at 1 A measuring current

Quick test

- Minimum test cycle only 20ms

Four-terminal test

- High precision measurement of low resistance

Various interface configuration


- External I / O port
- RS232 interface
- RS485 interface
- Ethernet interface
- Temperature test interface
- U disk interface

Power supply


- 100~256 V wide power supply
- Power frequency 50Hz/60Hz automatic identification
- Maximum power consumption 10W

1.3 Component name and functionality


Front Panel




Rear Panel

















Side view




Bottom



Keys	Description
	Function key F1
	Function key F2
	Function key F3
	Function key F4
	Function key F5
	Function key Escape Cancellation of operation
	Function key Enter Acceptance of settings and manual trigger input
	[Page Switch] Switch to [Test Page] <-> [Setup Page] <-> [Panel Page] <-> [Communication Settings Page] <-> [Sort Settings Page] <-> [I/O Settings page]
	Comparator on/off key


	<p>Lock key</p> <p>Short press [LOCK] key to lock the current page and the other keys get invalid. Long press to unlock.</p>
	<p>[0.ADJ] key</p> <p>Short press to zero-adjustment function, Long press to release the zero-adjustment function.</p>
	<p>[HOLD] key</p> <p>Hold the current measurement during the test</p>
	<p>[Trigger] key</p> <p>Single trigger test to the instrument in manual trigger mode</p>
	<p>[Direction] key</p> <p>Select menu items or set values</p>

1.4 Dimensions



1.5 Page composition

Measuring page



Parameter setting page

INT					
Test	Set	Panel	Comm	Sort	I/O
Trig Source	INT		Average	OFF	
Delay	000ms		Alarn	OFF	
OVC	OFF		Key Tone	OFF	
300mA	OFF		Language	English	
Temp Set	OFF				
INT	EXT	MAN	A.HOLD		

Parameter setting save page

INT					
Test	Set	Panel	Comm	Sort	I/O
No.	Name				
01	-----				
02	-----				
03	-----				
04	-----				
05	-----				
06	-----				
07	-----				
08	-----				
09	-----				
10	-----				
Empty					
Save					

Communication interface page

INT					
Test	Set	Panel	Comm	Sort	I/O
Interface	RS232				
Band Rate	9600				
RS232	RS485	TCP			

Sorting page

INT					
Test	Set	Panel	Comm	Sort	I/O
Sort	OFF				
Range	3mΩ				
No.	0				
Upper	-----				
Lower	-----				
OFF	ON				

I/o settings page



INT					
Test	Set	Panel	Comm	Sort	I/O
I/O level mode	NPN				
I/O output mode	Keep				
External I/O test	Start				
NPN	PNP				

Chapter II Preparing for Measurement



2.1 Measurement process overview

Follow these steps to prepare for measurement.

1. Turn off the power before disconnecting the power cord





2. Plug the power cord into the mains outlet





Ensure that the power cord is well grounded, which is conducive to the stability of the test.

3. Dial the power of the instrument to the "on" state



At this moment, the instrument inside has been turned on and it is in standby state.


4. Press and hold the panel POWER button to turn on the power.





When in the standby state, the panel POWER button light is red, long press the panel POWER button, the power is turned on, the screen is lit, and the panel button light turns green.

5. Set test parameters (see section 2.2 for details)


6. Start to test



7. End of test, turn off the power



2.2 Basic parameter setting process



2.3 Pre-measurement Inspection

Before using the instrument, inspect it to verify that no damage has occurred during storage or transportation and it operates normally. If you find any damage, contact your authorized distributor or reseller.

Instrument and peripheral checking

Inspection item	Action
Is there any damage or a crack in the instrument? Are the internal circuits exposed?	If any damage is found, do not use it. Return it for repair.
Is there any dust or contamination, such as pieces of metal, on any terminals?	If dust or contamination is adhered to a terminal, clean the terminal with a swab or the like.
Is the test lead coating broken or is the metal exposed?	If the coating of a test lead is broken, the measured value may become unstable or have an error. Replace the damaged test lead.

Power-on checking

Inspection item	Action
After turn on the power on at the back of the instrument, check instrument POWER button lit or not?	Return the instrument for repair, if the POWER button is not lit.
When you turn the power on, does the entire display turn on and then the model name and a measurement screen appear on the screen?	If the screen does not behave like this, the instrument may be damaged internally. Return it for repair.

2.4 Confirming the measured object

It is necessary to appropriately change the measurement conditions according to the object to be measured in order to reliably measure the resistance. Please refer to the recommended example shown in the table below to start measuring after setting up the instrument.

Measured object	Recommended setting		
	Temperature compensation temperature conversion	OVC function	Measuring current at 300mΩ range
Coil products	TC	OFF	Lo
Contact products	*1	ON	Lo
Conductive coating, conductive rubber	--	OFF	Lo
Metal wire, profile	*1	ON	Lo
Car grounding resistance	*1	ON	Hi

Coil products:

Coil products has large inductance components such as inductors, coils, transformers, and motor speakers. Under normal circumstances, when testing such products, avoid using the OVC function, because its inductance component will suppress the OVC current pulse. If the delay is not enough, the measurement will fail. Temperature compensation is required in some cases.

Contact products:

Relays, contactors, switches, etc. These products have a thermoelectric potential effect at the contacts due to the presence of contacts. The OVC function is recommended to eliminate the thermoelectric potential effect.

Metal wire, profile:

Such as metal wire, metal profiles, metal welded parts. Especially for wire rods, since the resistance value is relatively temperature dependent, it is recommended to use a low power test while using temperature compensation.

*1 When the temperature dependence of the object to be measured is large, use temperature compensation.

*2 Measurement values can be saved at regular intervals by using the interval measurement function.

2.5 Connecting Measurement Leads


**WARNING**

- To avoid electric shock accident, connect the test leads correctly.


**NOTE**

- To be safe, do not use any test lead other than the ones specified by our company.
- The ends of leads are sharp. Be careful to avoid injury.


Front panel connection



Example 9363-A Test clip



Example 9363-B Test Probe




Chapter III Basic Settings

In order to use the instrument correctly, you should read this chapter before performing the test.

3.1 Setting the test range

The range setting includes manual range and automatic range. The automatic range instrument will automatically select an appropriate range to test based on the value of the resistance being measured.



Manual Range Setting


In the measurement interface, press the [F 1] or [F 2] keys to switch the range, even when the automatic range function is turned on, the manual range switch is also effective (when the automatic range is turned on, the automatic range function is automatically turned off when the manual range is switched on) .

Ranges

3mΩ ↔ 30mΩ ↔ 300mΩ ↔ 3Ω ↔ 30Ω ↔ 300Ω
↔ 3kΩ ↔ 30kΩ ↔ 300kΩ ↔ 3MΩ

Auto-Ranging

In the measurement interface, press [F3] to switch the auto range. When at auto range, the [AUTO] mark is lit, and when the auto range is turned off, the [AUTO] mark is not displayed.



Note:


If the range is changed while the auto is ON, the auto range is automatically canceled and the manual range is set.

When the comparator function is turned ON, the range cannot be changed from fixed (it cannot be switched to auto-ranging). To change the range, turn OFF the comparator function or change the range from within the comparator settings.

When measuring certain motor, transformer or coil components, the auto range setting may not stabilize. In such cases, use manual range selection(see chapter Resistance measurement accuracy)

3.2 Setting the Measurement Speed

The measurement speed can be set to FAST (50 mea/sec), MED (medium (20 mea/sec)), or SLOW (2 mea/sec)




Note:

- When the measurement delay is set, the sampling period becomes slower.
- Test time includes ADC sampling, sorting output, and display time.
- In the test environment, when the electric field interference is relatively large, or when the test is difficult to stabilize, a slow test is recommended.

3.3 Temperature display settings


Press the [Temperature] key on the test page to switch whether the current temperature is displayed.



3.4 Setting the test trigger mode


The user can select internal trigger/external trigger/manual trigger/auto hold.

1. Select the parameter setting screen



Press [PAGE] Button to parameter setting page

2. Select the relevant menu items



Menu item	Meaning
[INT]	Internal
[EXT]	External
[MAN]	Manual
[A.HOLD]	Auto hold

3.5 Measurement delay setting

Set the delay time after changing the measurement current under OVC and auto range to adjust the measurement stabilization time. By using this function, even if the reactance component of the object to be measured is large, measurement can be started after the internal circuit is stabilized. The preset settings vary depending on the range or offset voltage compensation function.

Preset set OVC delay value (internal fixed) (unit: ms)

Measuring current	Range	Delay time (ms)
Lo	3mΩ ~ 30mΩ	200
	300mΩ ~ 3Ω	50
	30Ω ~ 300Ω	30
Hi	300mΩ	200

1. Select the parameter setting page



Press **[PAGE]** Button to parameter setting page

2. Select the relevant menu item

INT					
Test	Set	Panel	Comm	Sort	I/O
Trig Source	INT		Average	OFF	
Delay	000ms		Alarn	OFF	
OVC	OFF		Key Tone	OFF	
300mA	OFF		Language	English	
Temp Set	OFF				
Input					

F1



Press up/down/left/right to choose the menu

Approximate calculation criteria for inductive load delay time

- When applying a measurement current to an inductive load, it takes a certain amount of time to stabilize. When it is not possible to make measurements in the initial state (preset), please adjust the delay. Set the delay time to approximately 10 times the following calculated value to ensure that the reactance components (inductors, capacitors) do not affect the measured value.

$$t = -\frac{L}{R} \ln\left(1 - \frac{IR}{V_o}\right)$$

L : inductance of the measured object

R : resistance of the object to be measured + wire resistance + contact resistance

I : Measuring current

VO: open circuit voltage


- Initially set the delay time to a longer time and then gradually reduce the delay time while observing the measured value.

- If the delay time is extended, the display of the measured value will be slower.

3.6 OVC (thermal electromotive force compensation) function setting


OVC function automatically compensates for the electromotive force or the bias voltage inside the instrument. (OVC: Offset Voltage Compensation)

1. Select the parameter setting page



Press [PAGE] Button to parameter setting page


2. Select the relevant menu item




Menu item	Meaning
[OFF]	Turn on OVC function
[ON]	Turn off OVC function

3. OVC-on measurement page

When the OVC function is turned on, the OVC will be displayed on measurement page.



RP-RZ is displayed as the true resistance value based on the measured value RP when the measured current flows and the measured value RZ when the measured current does not flow.



V_{EMF} : It is a thermoelectric potential. When any metal is in contact, it will generate an electric potential. The magnitude of the electric potential is related to the temperature.

R_X : measured resistance

When the injection test current is I_M , $V_1 = V_{EMF} + R_X I_M$

When $I_M = 0$, $V_2 = V_{EMF}$

$V = V_1 - V_2 = R_X I_M$

The effect of the thermoelectric potential can be offset by a simple subtraction operation.

Note:

- When the offset voltage compensation function is ON (the OVC indicator is lit), the display of the measured value updates slowly.
- The OVC function cannot be used when the range is 3k Ω or more. It automatically changes to the OFF state.
- When the offset voltage compensation function has been changed, the zero adjustment function is released.
- When the inductance of the measured object is large, the delay time needs to be adjusted. (Initially set the delay time to a longer time and then gradually reduce it while observing the measured value.
- When the measured heat capacity of the object is small, the effect of the offset voltage compensation function may not be seen.

3.7 Switching measurement current 300mA (300m Ω range)

The instrument is able to change the measurement current of the 300m Ω range to 300 mA (100 mA at the factory). It is good to measure large current wiring under conditions close to the actual use state, it also helps to measure in an environment with large external noise.

1. Select the parameter setting interface



Press [PAGE] Button to parameter setting page

2. Select the relevant menu item

INT					
Test	Set	Panel	Comm	Sort	I/O
Trig Source	INT		Average	OFF	
Delay	000ms		Alarn	OFF	
OVC	OFF		Key Tone	OFF	
300mA	OFF		Language	English	
Temp Set	OFF				
OFF		ON			
F1		F2			

Menu item	Meaning
[OFF]	300mΩ range test current 100mA
[ON]	300mΩ range test current 300mA

3. The measurement page when 300mA measurement current is turned on

INT					
Test	Set	Panel	Comm	Sort	I/O
Range	300mΩ				
Speed	Slow				
Panel	Default				
Upper	OFF				
Lower	OFF				
<div style="display: flex; justify-content: space-between;"> 25.0°C </div> <div style="display: flex; justify-content: center; align-items: center;"> R: 100.00mΩ </div> <div style="display: flex; justify-content: center; gap: 20px; margin-top: 5px;"> 300mA 0.ADJ </div>					
Range ↑	Range ↓	Auto	Speed	Temp	


Note:

- When the measurement current is set to 300 mA, the power consumption of the object to be measured increases.
- When high-precision measurement is required, please use the 100 mA measurement current.
- If the measurement current is changed, the zero adjustment will be cleared.

3.8 Temperature compensation setting


The resistance value is converted to the reference temperature for display. When performing temperature compensation, connect the temperature probe to the TC terminal on the rear panel of the instrument.

1. Select the parameter setting page




Press **[PAGE]** Button to parameter setting page


2. Select the relevant menu item



3. The measurement page when the temperature compensation is on.




After the temperature compensation is set to ON, the setting requires the reference temperature and temperature coefficient. The default setting is 20°C and the temperature coefficient is 3930ppm/°C (the temperature coefficient of pure copper material at 20°C)



Press up/down/left/right to choose the menu

The compensation principle is as follows:



$$R_{t0} = \frac{R_t}{1 + \alpha_{t0}(t - t_0)}$$

R_t : measured resistance value

R_{t0} : compensation resistance value

t : measuring temperature

T_0 : Base stability (Setting range -10°C to 99.9°C)

α_{t0} : temperature coefficient at t_0 of the material to be tested

(setting range -9999ppm/°C to 9999ppm/°C)

Note:

When “t.error” is displayed, it indicates that the temperature probe is not connected or the temperature is displayed as ---.-. Please confirm the connection of the temperature probe.

3.9 Average function


The averaging function averages multiple measured values and displays the results. It can be used to reduce variation in measured

values

Average times:


OFF ↔ 2 ↔ 5 ↔ 10 ↔ 20

1. Select the parameter setting page



Press **[PAGE]** Button to parameter setting page

2. Select the relevant menu item



Menu item	Meaning
[OFF]	Average function is OFF
[2]	Get average of 2 measurements to display
[5]	Get average of 5 measurements to display
[10]	Get average of 10 measurements to display
[20]	Get average of 20 measurements to display


3.10 Setting Beep

After instrument comparator is turned on or test result of sorting opening output is judged, the instrument beep mode can be

selected.


Beep mode :
OFF ↔ HI ↔ LOW ↔ IN ↔ HI_LOW

1. Select parameter setting menu



Press [PAGE] Button to parameter setting page

2. Select related menu items



Menu	Description
[OFF]	Beep is turned off
[HI]	Beep when exceed upper limit
[LOW]	Beep when less than lower limit
[IN]	Beep when PASS
[HI_LOW]	Beep when exceed upper limit Or less than lower limit

3.11 Button Sound Setting


Users can choose whether to turn on the button sound when operating instrument keys.

1. Select parameter setting menu



Press **[PAGE]** Button to parameter setting page

2. Select related menu items



Menu	Description
[OFF]	Sound is turned off
[ON]	Sound is turned on

3.12 Language setting

You can select the system language of the instrument.

1. Select parameter setting menu



Press **[PAGE]** Button to parameter setting page

2. Select related menu items

INT					
Test	Set	Panel	Comm	Sort	I/O
Trig Source	<input type="text" value="INT"/>		Average	<input type="text" value="OFF"/>	
Delay	<input type="text" value="000ms"/>		Alarn	<input type="text" value="OFF"/>	
OVC	<input type="text" value="OFF"/>		Key Tone	<input type="text" value="OFF"/>	
300mA	<input type="text" value="OFF"/>		Language	<input type="text" value="English"/>	
Temp Set	<input type="text" value="OFF"/>				
中文	English				

F1




F2

3.13 Comparator Function

3.13.1 Comparing result signal output method

When comparator function is turned on, instrument provides three alarm outputs:

1. LED light at front panel alarm

COMP	
 HI	Measure value > Upper limit value
 IN	Upper limit value \geq Measure value \geq Lower limit value
 LO	Measure value < Lower limit value

2. Sound alarm

Please refer to chapter 3.10.

3. External IO interface, signal output

Please refer to chapter 6.1

3.13.2 Comparison Mode

There are 3 comparison modes: [upper limit comparing]/[lower limit comparing]/[upper and lower limit comparing]



Example:

Sorting mode	Upper limit value	Lower limit value	Pass	Fail
upper limit comparison	100Ω	----	Measuring value ≤ 100Ω	Measuring value > 100Ω
lower limit comparison	----	10Ω	Measuring value ≥ 10Ω	Measuring value < 10Ω
upper and lower limit comparison	100Ω	10Ω	10Ω ≤ Measuring value ≤ 100Ω	Measuring value ≥ 100Ω Or Measuring value ≤ 10Ω

How to set:


Sorting mode	Setting up procedure
Upper limit comparison	Upper limit ON input value is valid, lower limit turned off (----)
lower limit comparison	Lower limit ON input value is valid, upper limit turned off (----)
upper and lower limit comparison	Both lower limit and lower limit input value are valid

1. Enter comparator to set up




Press **[COMP]** key to enter comparator setting menu

2. Turn on the upper and lower value comparison comparing




3. Set the upper and lower limits after the upper and lower limits comparison value is turned on



3.13.3 Setting upper and lower limits & compare mode


When upper limit comparing mode is turned on ,

1. Upper limit value setting



Press up/down/left/right to choose the menu

2. Lower limit value setting



Press up/down/left/right to choose the menu

3.14 Sorting Function

The comparison between the upper and lower limits of one measurement and up to 10 groups (P0~P9) is performed by the classification measurement, and measurement result is displayed. All items not included in the BIN are judged as NG. The sorting result can also be output via EXT I/O terminal.


3.14.1 Sorting Function Opening Setting

1. Select parameter setting menu



Press [PAGE] Button to parameter setting page

2. Select related menu items



The screenshot shows a menu with buttons 'Test', 'Set', 'Panel', 'Comm', 'Sort', and 'I/O'. Above the 'Sort' button is the label 'INT'. The 'Sort' button is highlighted. Below the menu, the 'Sort' function is set to 'OFF'. Other parameters are: Range (3mΩ), No. (0), Upper (-----), and Lower (-----). At the bottom, there are two buttons: 'OFF' and 'ON'.

Tips:

- If sort function is ON, the comparator cannot be set to ON.
- The range cannot be changed while sorting function is in use. To change the range, please make changes on the sorting settings page.

3.14.2 Sorting Function Range Setting

Range:

3mΩ ↔ 30mΩ ↔ 300mΩ ↔ 3Ω ↔ 30Ω ↔ 300Ω ↔
3kΩ ↔ 30kΩ ↔ 300kΩ ↔ 3MΩ

After sorting function is turned on, range is turned off automatically.

INT					
Test	Set	Panel	Comm	Sort	I/O
Sort	<input type="text" value="ON"/>	BIN0	H:----	L:----	
		BIN1	H:----	L:----	
Range	<input type="text" value="3mΩ"/>	BIN2	H:----	L:----	
		BIN3	H:----	L:----	
No.	<input type="text" value="0"/>	BIN4	H:----	L:----	
		BIN5	H:----	L:----	
Upper	<input type="text" value="-----"/>	BIN6	H:----	L:----	
		BIN7	H:----	L:----	
Lower	<input type="text" value="-----"/>	BIN8	H:----	L:----	
		BIN9	H:----	L:----	
3mΩ	30mΩ	300mΩ	3Ω	NEXT	
<input type="button" value="F1"/>	<input type="button" value="F2"/>	<input type="button" value="F3"/>	<input type="button" value="F4"/>	<input type="button" value="F5"/>	

3.14.3 Sorting Function Group No. Setting

INT					
Test	Set	Panel	Comm	Sort	I/O
Sort	<input type="text" value="ON"/>	BIN0	H:----	L:----	
		BIN1	H:----	L:----	
Range	<input type="text" value="3mΩ"/>	BIN2	H:----	L:----	
		BIN3	H:----	L:----	
No.	<input type="text" value="0"/>	BIN4	H:----	L:----	
		BIN5	H:----	L:----	
Upper	<input type="text" value="-----"/>	BIN6	H:----	L:----	
		BIN7	H:----	L:----	
Lower	<input type="text" value="-----"/>	BIN8	H:----	L:----	
		BIN9	H:----	L:----	
0	1	2	3	NEXT	
<input type="button" value="F1"/>	<input type="button" value="F2"/>	<input type="button" value="F3"/>	<input type="button" value="F4"/>	<input type="button" value="F5"/>	

3.14.4 Sorting Function Upper Limit Setting

When range and group number settings are completed, corresponding upper limit value can be set. The upper limit unit is the same as that of range.

INT					
Test	Set	Panel	Comm	Sort	I/O
Sort	<input type="text" value="ON"/>	BIN0	H:----	L:----	
		BIN1	H:----	L:----	
Range	<input type="text" value="3mΩ"/>	BIN2	H:----	L:----	
		BIN3	H:----	L:----	
No.	<input type="text" value="0"/>	BIN4	H:----	L:----	
		BIN5	H:----	L:----	
Upper	<input type="text" value="-----"/>	BIN6	H:----	L:----	
		BIN7	H:----	L:----	
Lower	<input type="text" value="-----"/>	BIN8	H:----	L:----	
		BIN9	H:----	L:----	
On					



3.14.5 Sorting Function Lower Limit Setting


When range and group number settings are completed, corresponding lower limit value can be set. The lower limit unit is the same as that of range.

INT					
Test	Set	Panel	Comm	Sort	I/O
Sort	<input type="text" value="ON"/>	BIN0	H:----	L:----	
		BIN1	H:----	L:----	
Range	<input type="text" value="3mΩ"/>	BIN2	H:----	L:----	
		BIN3	H:----	L:----	
No.	<input type="text" value="0"/>	BIN4	H:----	L:----	
		BIN5	H:----	L:----	
Upper	<input type="text" value="-----"/>	BIN6	H:----	L:----	
		BIN7	H:----	L:----	
Lower	<input type="text" value="-----"/>	BIN8	H:----	L:----	
		BIN9	H:----	L:----	
On					



3.14.6 Return to Display Page

The display page after sorting function is turned on




Chapter IV Measuring

This chapter provides step-by-step descriptions of the functions used for proper measurement, including start-up settings, range scopes, and protection function startup.

4.1 Starting

1. Set relevant parameters
2. Connect test leads correctly
3. When test starts, the logo in the upper left corner of screen will flash according to the test speed.



Trigger Mode	Description
Internal Trigger	Automatic trigger test inside the instrument

External Trigger	Trigger test via external EXT IO terminal TRG signal
Manual Trigger	Manually press [TRG], RS232, LAN port command to trigger the test.
Auto Hold	Automatic test to be measured to maintain the current resistance value

Tips:

- Users cannot start another test when the test has not completed.
- When the EOC signal of the EX.I/O port is LOW, the test cannot be triggered.

4.2 Measuring Value Display


The following is the test range. Once the following range is exceeded, OF is displayed (over the range)

Test current and range:

Resistance Range	Test Current	Max Reading	Resolution (Ω)
3m Ω	1A	3.2000m Ω	0.1 $\mu\Omega$
30m Ω	1A	32.000m Ω	1 $\mu\Omega$
300m Ω	300mA	320.00m Ω	10 $\mu\Omega$
	100mA		
3 Ω	100mA	3.2000 Ω	100 $\mu\Omega$
30 Ω	10mA	32.000 Ω	1m Ω
300 Ω	1mA	320.00 Ω	10m Ω
3k Ω	1mA	3.2000k Ω	100m Ω
30k Ω	100uA	32.000k Ω	1 Ω
300k Ω	10uA	320.00k Ω	10 Ω
3M Ω	1uA	3.2000M Ω	100 Ω

4.3 Automatic Protection Function

If an overvoltage is input to the measurement terminals, internal circuit protection function of the instrument is activated. If users input an overvoltage incorrectly, please remove the test leads immediately from the object under test. Measurements cannot be made during the protection function action. To release the protection function, please touch the test cable DRIVE+ and DRIVE- or re-energize.



4.4 Perform Clear Zero

Please perform clear zero in the following cases. (Can cancel the resistance below $\pm 3\%$ f.s. for each range)

- When residual display content occurs due to effected by such as electromotive force

→ The display changes to zero.

The accuracy specification does not change no matter it is zeroed or not.

The electromotive force can also be cancelled by the OVC.

- When it is difficult to perform 4-terminal wiring (Kelvin connection)

→ Cancel the remaining resistance of the 2 terminal wiring.


Tips:


- After clear zero has been made, if the ambient temperature changes or the test lead is changed, please perform zero adjustment again.
- Please perform zero adjustments for all ranges used. In the manual range, clear zero is performed only in the current range; in the automatic range, zero adjustment is performed in all ranges.
- The zero value is saved internally even if the power is turned off, but it is not saved to the panel.
- When offset voltage compensation function (OVC) is switched from ON to OFF or from OFF to ON, zero adjustment is released. Please perform clear zero again.
- When measurement current is switched from Lo to Hi or from Hi to Lo, zero adjustment is released. Please perform zero adjustment again.
- If the resistance is measured to be smaller than the resistance at zero, the measured value is negative.

Example: Connect 1mΩ for zero adjustment in the 300mΩ range → If measuring 1mΩ, it shows -1mΩ


1. Short –circuit test leads

9363-A Clip type test leads






9363-B Probe type test leads




2. Confirm that the measured value is within $\pm 3\%$ s.

If measured value is not displayed, check that the test leads are connected correctly.



When the wiring is correct



When the wiring is Wrong



3. Clear Zero



Press the [0.ADJ] button to perform zero adjustment.

4. After zero adjustment

If clear zero is successful, the icon will be displayed in the lower right corner of the display measurement and then return to the measurement state. If zero adjustment failed, the icon is not displayed, the measurement state is returned.

Zero adjustment failed

When zero adjustment is not possible, it may be that the measured value before zero adjustment exceeds $\pm 3\%$ of the full scale of each range, or it is in a test abnormal state. Please make the correct wiring again and re-zero. Due to the resistance value of a self-made cable is high, it cannot be zeroed, please reduce the wiring resistance.

Tip:


When the zero adjustment fails, the zero adjustment of the current range will be released.

5. Contact zeroing

On the measurement page, press and hold the [O.ADJ] button to release the zero value of the current range.

Chapter V Measure Panel Save


All measurement conditions can be saved, retrieved or deleted in the form of files. Press [PAGE] to enter measurement setting save page.



Press [PAGE] Button to panel page

After entering this page, and pressing up and down keys, users can refer to the saved record, which can save, load, clear, rename, etc. the current record.

5.1 Save Panel Setting



Press up/down/left/right to choose the menu



Use up and down keys to review current settings and press Save button to save current settings.

Test		Set	Panel	Comm	Sort	I/O
No.	Name	Range 3mΩ	OVC OFF			
01	PANEL 01	Speed Slow	300mA OFF			
02	-----	Trig INT	Average OFF			
03	-----	Delay OFF	Alert OFF			
04	-----	Upper -----	Lower -----			
05	-----	Temp Set OFF				
06	-----					
07	-----					
08	-----					
09	-----					
10	-----					

Save Load Clear Rename

F1 F2 F3 F4



Press up/down/left/right to choose the menu

5.2 Retrieve Measuring Setting

Test		Set	Panel	Comm	Sort	I/O
No.	Name	Range 3mΩ	OVC OFF			
01	PANEL 01	Speed Slow	300mA OFF			
02	-----	Trig INT	Average OFF			
03	-----	Delay OFF	Alert OFF			
04	-----	Upper -----	Lower -----			
05	-----	Temp Set OFF				
06	-----					
07	-----					
08	-----					
09	-----					
10	-----					

Press Enter to load


1 press **F2** to choose load

2 press **ENTER** to confirm load

Use up and down keys to review current settings and press Load button to retrieve current settings.

5.3 Delete Measuring Setting

INT					
Test	Set	Panel	Comm	Sort	I/O
No.	Name	Range 3mΩ	OVC OFF		
01	PANEL 01		300mA OFF		
02			Average OFF		
03			Alert OFF		
04			Upper ----- Lower -----		
05			Temp Set OFF		
06					
07					
08					
09					
10					


1 press  to choose clear

2 press  to confirm clear

Use up and down keys to review current settings and press Clear key to delete current settings.

5.4 Rename Measuring Setting

INT					
Test	Set	Panel	Comm	Sort	I/O
No.	Name	Range 3mΩ	OVC OFF		
01	PANEL 01	Input name	300mA OFF		
02			Average OFF		
03			Alert OFF		
04			Upper ----- Lower -----		
05			Temp Set OFF		
06					
07					
08					
09					
10					




Press up/down/left/right to choose the menu




Use up and down keys to review the current settings and press Rename button to modify current file name.

Chapter VI EXT I/O port (Handler)

The EXT I/O connector on the rear of the instrument supports external control by providing output of the EOM and comparator judgment signals, and accepting input of TRIG and KEY_LOCK signals. All signals are isolated from the measurement circuit and ground (I/O common pins are shared). Input circuit can be switched to accommodate either current sink output (NPN) or current source output (PNP).



PNP (current source) wiring




Level mode setting

- Select the I/O page




Press **[PAGE]** Button to I/O page

- Select I/O level mode




Output mode setting

- Select the I/O page




Press **[PAGE]** Button to I/O page

- Select I/O output mode




- Select pulse and set the output time




6.1.2 Port Signals description

The EXT I/O port connector uses the D-SUB female terminal of the 36-PIN pin.

Figure:



Port layout



(Instrument side)

PIN	signal	Functions	I/O	Logic
1	TRG	Trigger test	I	Edge trigger
2	--	--	--	--
3	--	--	--	--

4	LOAD1	Panel selection	I	Level
5	LOAD3	Panel selection	I	Level
6	ISO_5V	Isolated power supply 5V	O	--
7	ISO_COM	Isolated power ground	O	--
8	ERR	Automatic protection open	O	Level
9	HI	measurement value > upper limit value	O	Level
10	LOW	measurement value < lower limit value	O	Level
11	BIN0	Bin P0	O	Level
12	BIN1	Bin P1	O	Level
13	BIN2	Bin P2	O	Level
14	BIN3	Bin P3	O	Level
15	BIN4	Bin P4	O	Level
16	BIN5	Bin P5	O	Level
17	BIN6	Bin P6	O	Level
18	BIN7	Bin P7	O	Level
--	--	--	--	--
20	LOAD0	Panel selection	I	Level
21	LOAD2	Panel selection	I	Level
22	--	--	--	--
23	GD	Qualified output	O	Level
24	NG	Unqualified output	O	Level
25	--	--	--	--
26	ISO_COM	Isolated common signal ground	O	--


27	EOC	End of Level measurement	O	Level
28	IN	IN Sort	O	Level
29	BIN8	Bin P8	O	Level
30	BIN9	Bin P9	O	Level
31	OB	Bin NG	O	Level
32	--	--	--	--
33	--	--	--	--
34	--	--	--	--
35	--	--	--	--
36	--	--	--	--

6.1.3 Port Signal Connection Method


Electrical performance parameter

Input signals	Type	Optocoupler input
	ON	Internal conduction current : 4mA or more the max voltage drop :1V
	OFF	Input current less than 100 μ A
output signals	Type	Optocoupler output, open drain output
	Maximum load voltage	30V DCMAX
	Maximum output circuit	50mA/channel
	Output voltage drop	1VMIN (at 50mA conditions)
Internal isolated current source	Rated voltage	+5V (NPN), -5V (PNP)
	Rated current	100mA
	Isolation condition	Isolated from internal circuitry, floating


Input circuit wiring




switched input



relay input




PLC's NPN output




PLC's PNP output


Output circuit wiring




Drive relay




Drive LED lamp




Logic level output



Level or operation



PLC's NPN input




PLC's PNP input

6.2 Timing Chart

Each signal level indicates the ON/OFF state of a contact. When using the current source (PNP) setting, the level is the same as the EXT I/O pin voltage level. When using the current sink (NPN) setting, the high and low voltage levels are reversed.


6.2.1 Timing chart for external triggering

External trigger [EXT] setting (EOC output hold)



	Item	Timing
T1	TRG, Signal pulse width	5msMIN
T2	delay	5msMAX
T3	ADC sampling time	Fast 20ms Medium 50ms Slow 500ms
T4	Data processing time	5msMAX

External trigger [EXT] setting (EOM output pulse)




	Item	Timing
T1	TRG, Signal pulse width	5msMIN
T2	delay	5msMAX
T3	ADC sampling time	Fast 20ms Medium 50ms Slow 500ms
T4	Data processing time	5msMAX
T5	Judgment result pulse time	available (1ms~999ms)

6.2.2 Reading process at external triggering

The following table shows from start of measurement to acquisition of judgment results

The EOC signal is output immediately after the instrument determines the judgment result (HI, IN, LOW, ER, GD, NG). If the controller's input circuit response is slow, it may be necessary to insert wait processing after EOM=ON is received until the judgment results are acquired



6.3 External Control Checking


In addition to switching output signals ON and OFF manually, you can view the input signal state on the screen.

- Select the I/O page




Press **[PAGE]** Button to I/O page

- Select the I/O settings page





- Select the manually I/O test page



Output signal, operable signal (OFF: turn off the output ON: turn on the output)

Input signal, display the status of the signal (ON: reverse display OFF: normal display)

- Exit the I/O test page



Back to I/O setting

Chapter VII Communications

The instrument has three communication modes, one is RS232 communication, one is RS485 communication, the other is Lan (network protocol using TCP) communication mode. The three modes of communication protocol all adopt SCPI protocol.





Do not connect the communication port to the measurement port, as this may damage the instrument.

7.1 RS232 communication


The RS232 communication uses a 3-wire communication method.

Interface and cable




9-pin D-Sub mother port

RS232 Connection Mode




RS232 setting

- Select the Comm page




Press **[PAGE]** Button to Comm page

- Select RS232 communication mode




➤ Select the baud rate



7.2 RS485 communication


The RS485 communication uses a 3-wire communication method.

RS485 Connection Mode



RS485 setting

➤ Select the Comm page



Press [PAGE] Button to Comm page

➤ Select RS485 communication mode

INT					
Test	Set	Panel	Comm	Sort	I/O
Interface	RS485				
Band Rate	9600				
Address	255				
RS232	RS485	TCP			
F1	F2	F3			

➤ Select the baud rate

INT					
Test	Set	Panel	Comm	Sort	I/O
Interface	RS485				
Band Rate	9600				
Address	255				
9600	19200	38400			
F1	F2	F3			

➤ Enter the address


INT					
Test	Set	Panel	Comm	Sort	I/O
Interface	RS485				
Band Rate	9600				
Address	255				
Input					
F1					

7.3 LAN communication

LAN port communication uses TCP protocol communication.

Interface and cable

The Ethernet uses the standard RJ45 port, and the cable uses Category 5 for the Internet cable.



Connection method

Instrument and computer connection

When the instrument is connected to a computer, the network cable uses a crossover cable.

Using T568B color code wiring standards to connect A side

Orange /White	Orange	Green/ white	Blue	Blue/ white	Green	Brown /white	Brown
------------------	--------	-----------------	------	----------------	-------	-----------------	-------

Using T568A color code wiring standards to connect B side

Green /white	Green	Orange /White	Blue	Blue/ white	Orange	Brown /white	Brown
-----------------	-------	------------------	------	----------------	--------	-----------------	-------


Instrument and computer connection

When the instrument is connected to the router, the network cable is directly connected.

Orange /White	Orange	Green/ White	Blue	Blue/ White	Green	Green/ White	Brown
------------------	--------	-----------------	------	----------------	-------	-----------------	-------

Setting


- Select the communication page



Press [PAGE] Button to Comm page

- Select TCP communication mode

A screen with a menu at the top containing 'Test', 'Set', 'Panel', 'Comm', 'Sort', and 'I/O'. Above the 'Sort' button is the text 'INT'. Below the menu, the text 'Interface' is followed by 'TCP' in a highlighted box. Below that, 'IP address' is followed by '192.168.001.199' in a box. Below that, 'Port No.' is followed by '502'. At the bottom, there are three buttons labeled 'RS232', 'RS485', and 'TCP', with 'TCP' being the selected option.



- Set the communication page

A screen with a menu at the top containing 'Test', 'Set', 'Panel', 'Comm', 'Sort', and 'I/O'. Above the 'Sort' button is the text 'INT'. Below the menu, the text 'Interface' is followed by 'TCP' in a box. Below that, 'IP address' is followed by '192.168.001.199' in a highlighted box. Below that, 'Port No.' is followed by '502'. At the bottom, there is a button labeled 'Input'.



Chapter VIII Specification

8.1 General Specification

General function

Measurement parameters	DC resistance
Basic parameters:	0~3.3MΩ (10 ranges) Max reading:33000 Min resolution: 0.1μΩ
Basic accuracy	0.1%±10 count(3mΩ,30mΩ,3MΩ) 0.05%±4 count(300kΩ) 0.02%±2 count(other range)
Measurement range	3mΩ/30mΩ/300mΩ/3Ω/30Ω/300Ω/3kΩ/30kΩ/300kΩ/3.3MΩ.
Measuring speed	FAST(50Hz:21ms, 60Hz:18ms) SLOW(200ms)
Signal Source	1A DC Max:5.5V
Temperature	Range:-10 °C~60 °C, Accuracy:1 °C
Calibration	Short-circuit reset for all ranges
Comparator	10-bin sorting, output signal HIGH/IN/LOW
Internal data storage	6000 group test data
Trigger mode	IO, bus, manual
Interface	External IO Analog LAN RS-232C
Other	Temperature compensation function Comparator(ABS/REF%)

	Lock(OFF/menu lock/all lock) Power frequency setting(auto/50Hz/60Hz), Zoom in/out Judge sound setting Auto-save Average function Panel storage/reading
Power supply	Voltage:100VAC ~ 240VAC; Frequency: 50Hz ~ 60Hz;Power: max 10VA
Dimension & weight	325 mm (L)x215mm (W)x96mm (D); Weight: 2kg
Max output current	1A
Automatic protection display	"Protet"
Display when Range over limit	Display OF
Input terminal	Banana plug
Operation key	Rubber key
Display screen	3.5 inch TFT
Precision guarantee period	1 year
Operating temperature and humidity	0°C to 40°C 80% RH or less (no condensation)

Storage temperature and humidity	-10 to 60°C 80% RH or less (no condensation)
Operating environment	Indoor, the highest altitude is 2000m

8.2 Accuracy

The following indicators test conditions:

Temperature: 20±3°C

Humidity: <80% RH

Warm-up time is more than 15 minutes

Calibration time is less than 1 year

Resistance measurement accuracy:

Range		Resolu tion	Fast speed %rdg.+%f.s.	Medium speed, slow speed %rdg.+%f.s.	Test current
1	3mΩ	0.1μΩ	0.1+0.03	0.1+0.03	1A
2	30mΩ	1μΩ	0.1+0.03	0.1+0.03	1A
3	300mΩ	10μΩ	0.1+0.02	0.1+0.02	300mA
			0.1+0.02	0.05+0.02	100mA
4	3Ω	100μΩ	0.1+0.01	0.02+0.01	100mA
5	30Ω	1mΩ	0.1+0.01	0.02+0.01	10mA
6	300Ω	10mΩ	0.1+0.01	0.02+0.01	1mA
7	3kΩ	100mΩ	0.1+0.01	0.02+0.01	1mA
8	30kΩ	1Ω	0.1+0.01	0.02+0.01	100uA
9	300kΩ	10Ω	0.1+0.02	0.05+0.02	10uA
10	3M	100Ω	0.3+0.03	0.2+0.03	1uA